

User Manual

Regular maintenance is crucial for safety, tyre longevity, and vehicle performance.

- **Check Pressure Monthly:** Use a reliable gauge when tyres are cold. The correct PSI is listed in your vehicle's manual or on the driver's side door jamb. Caution: Both under-inflation and over-inflation can lead to premature wear, poor handling, overheating, and sudden tyre failure.
- **Inspect for Damage and Tread Wear:** Look for cuts, cracks, bulges, or embedded objects. The minimum legal tread depth is 1.6mm (2/32 inch).
- **Understand Tread Wear Indicators (TWI):** Look for the "TWI" mark or a small triangle on the tyre's sidewall. This marks the grooves where narrow rubber bars (wear bars) are located. When the tread surface is level with these bars, your tyre is worn out and must be replaced immediately.
- **Regular Rotation and Alignment:** To promote even tread wear and extend tyre life, rotate your tyres every 10,000 kilometers (or as per your vehicle manufacturer's schedule). Keep wheels properly aligned to prevent uneven wear patterns.
- **Avoid Mixing Tyre Types:** For optimal safety, do not mix radial tyres with bias-ply tyres on the same vehicle. Their different handling characteristics can be dangerous.

Warranty & Customer Support

Double Horse Tyre is committed to high-quality manufacturing standards. Each tyre is backed by a comprehensive warranty covering defects in workmanship and materials. For full warranty terms, claims, and returns, please visit our dedicated support page or contact us directly.

Proper Disposal

When your Double Horse Tyre reaches the end of its service life, always dispose of it through a certified recycling center. Never attempt to burn or bury used tyres, as this causes serious environmental harm.